

01	02	03	04	05	06	07	08	09	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24

01	:	FRONT LEFT (-)
02	:	FRONT LEFT (+)
03	:	REAR RIGHT (-)
04	:	REAR RIGHT (+)
05	:	REAR LEFT (+)
06	:	REAR LEFT (-)
07	:	FRONT RIGHT (+)
08	:	FRONT RIGHT (-)
09	:	N/A
10	:	N/A
11	:	N/A
12	:	GROUND
13	:	12V (+) MEMORY
14	:	N/A
15	:	N/A
16	:	N/A
17	:	N/A
18	:	AMP. TURN-ON
19	:	?
20	:	DIMMER
21	:	N/A
22	:	?
23	:	12V (+) IGNITION
24	:	N/A